


1150

Zirconia - Alumina - Metal Primer

Instructions for Use



restoration according to manufacturer's instructions. The restoration should be performed prior to placement of Z-PREP.

1. Brush on 1-2 coats of **Z-PRIMER** on the second and air dry. **NOTE:** Primer should be same before and after primer.
2. Try-in the primer treated restoration.
3. Rinse the restoration thoroughly.

NOTE: If the surface was not pre-treated, the surface with a cleaning agent and air dry with oil-free air. Then follow the instructions for the primer.

Patent No. 8 785 518

Repair of Zirconia/Alumina

1. Roughen the surface using 600-grit sand paper and air dry.
2. Apply 1-2 coats of Z-PRIME[®] and recoat.

Rev. 9/21

[illegible]

[illegible]